

ELM-35-5.6-16-C test report Optotune/Kowa 35mm lens

Coptotune EL-1640

June 2021

Dr. Gustavo Ciardi, Application Engineer

Optotune Switzerland AG | Bernstrasse 388 | CH-8953 Dietikon | Switzerland Phone +41 58 856 3011 | www.optotune.com | info@optotune.com

Compact, off-the-shelf fixed focal length lens with autofocus

> In combination with up to 1" camera, a **full imaging system** with:

✓ Compact form factor
 ✓ Fast focusing and Autofocus
 ✓ High resolution accross all FOV
 ✓ Great mono- and polychromatic performance
 ✓ Orientation independent resolution



- Ideal for applications with medium field of view:
 - ✓ Robot Vision
 ✓ Bottle inspection
 ✓ Electronics inspection





1 This information is confidential to Optotune and is not to be copied or forwarded to any 3rd party without our prior written consent.



> Large working distance (WD) range

- From 250 mm to infinity
- Optical leverage 150 mm/dpt in the 250-750 mm range
- Angular Field of View with 1" sensor (horizontal): 24°
- **Resolution** suitable for 3.45 um pixel size:
 - Nyquist limit (up to 144 lp/mm) almost everywhere in the FOV at F/5.6
 - Resolution at F/11 limited by diffraction

> Image quality

- No distortion
- Great polychromatic and monochromatic performance
- Same vertical and horizontal optical axis performance



Test setup





Methods for image evaluation

After acquisition, images are zoomed in to show resolution limited element





WD = 250 mm, @ 3 dpt, F/5.6, HFOV = 113 mm

Camera

Sensor size = 3678×2782 pixels Nyquist limit = 144 lp/mm Pixel size = 3.45 um

Light

Red background illumination

Center



Edge

Corner







4/1



USAF element:
Line width (um):
Lp/mm (object):
Magnification:
In/mm (image)

4/1	
31.25	
16	
0.115	
139	

4/1	
31.25	
16	
0.115	
139	



3/6



WD = 250 mm, @ 3 dpt, F/11 loss of resolution due to diffraction



WD = 500 mm, @ 0.56 dpt, F/5.6, HFOV = 203 mm

Camera	Center	Edge	Corner
Sensor size = 3678x2782 pixels Nyquist limit = 144 lp/mm Pixel size = 3.45 um			
Light			
Red background illumination			
USAF element:	3/2	3/1	3/1
Line width (um):	55.68	62.5	62.5
Lp/mm (object):	9	8	8
Magnification:	0.064	0.064	0.064
Lp/mm (image):	140	124	124

7 This information is confidential to Optotune and is not to be copied or forwarded to any 3rd party without our prior written consent.



WD = 750 mm, @ -0.3 dpt, F/5.6, FOV = 317 mm

Center Edge Camera Corner Sensor size = 3678×2782 pixels 11= Nyquist limit = 144 lp/mmPixel size = 3.45 um Light Red background illumination **USAF** element: 2/4 2/4 2/3 88.39 99.21 Line width (um): 88.39 5 Lp/mm (object): 6 6 0.041 0.041 Magnification: 0.041 Lp/mm (image): 138 138 123





Monochromatic vs white light



No loss of image quality with white light!

This information is confidential to Optotune and is not to be copied or forwarded to any 3rd party without our prior written consent. 9



Benchmark without liquid lens, WD 405 mm, F/5.6

17mm of spacer added to compensate for EL-16-40 thickness

Camera

Sensor size = 3678x2782 pixels Nyquist limit = 144 lp/mm Pixel size = 3.45 um

Light

Red background illumination

Center



Edge

Corner







3/4	
44.19	
11	
0.081	
140	

3/	3	1		
49 10	, O.)	T		

0.081

125



3/2 55.68 9 0.081 111



With liquid lens @ 1.12 dpt, WD 405 mm, F/5.6

Camera

Sensor size = 3678x2782 pixels Nyquist limit = 144 lp/mm Pixel size = 3.45 um

Light

Red background illumination

USAF element:

Line width (um):

Lp/mm (object):

Lp/mm (image):

Magnification:



ptotune

Comparison with/without liquid lens



No loss of image quality with liquid lens!



With



With liquid lens @ 1.12 dpt, WD 405 mm, F/#=5.6 Horizontal optical axis

Camera

Sensor size = 3678x2782 pixels Nyquist limit = 144 lp/mm Pixel size = 3.45 um

Light

Red background illumination

USAF element:

Line width (um):

Lp/mm (object):

Lp/mm (image):

Magnification:



0.081

125

Corner





3/2 55.68 9 0.081



13 This information is confidential to Optotune and is not to be copied or forwarded to any 3rd party without our prior written consent.

0.081

140

Comparison horizontal/vertical optical axis



Edge



Corner





Vertical







No loss of image quality in horizontal optical axis!

