



shaping the future of optics

# Schneider Kreuznach PYRITE 4.0-60 C-LF-SD with EL-16-40-TC-VIS-5D

Zürich, March 2022

Dr. Gustavo Ciardi, Application Engineer

Optotune Switzerland AG | Bernstrasse 388 | CH-8953 Dietikon | Switzerland  
Phone +41 58 856 3011 | [www.optotune.com](http://www.optotune.com) | [info@optotune.com](mailto:info@optotune.com)

# Summary

---

- Almost Nyquist limited performance along the WD range (very good also on corner and edges)
- Good correlation with the MTFs on the datasheet
- Visible coma in Horizontal optical axis at F/4, better at F/5.6
- Decent performances in Horizontal optical axis overall


# Test setup



Camera:	1.1" (IDS UI-3200SE-M) 4104x3006 pixels, 3.45 um px
Lens:	PYRITE 4.0-60 C-LF-SD with EL-16-40-TC-VIS-5D embedded
F/#	4-32
Driver:	Optotune Lens Driver 4
Target:	Transparent USAF target
Light:	White backlight
Optical axis:	Vertical


# Method for image evaluation

- After acquisition, images are zoomed in to show resolution limited element




# Relative illumination plots ( $\beta = \text{magnification}$ )

- - F/# = 4.0,  $\beta = -0.10$
- - F/# = 5.6,  $\beta = -0.10$
- - F/# = 8.0,  $\beta = -0.10$
- F/# = 4.0,  $\beta = -0.12$
- F/# = 5.6,  $\beta = -0.12$
- F/# = 8.0,  $\beta = -0.12$
- ⋯ F/# = 4.0,  $\beta = -0.14$
- ⋯ F/# = 5.6,  $\beta = -0.14$
- ⋯ F/# = 8.0,  $\beta = -0.14$



- - F/# = 4.0,  $\beta = -0.15$
- - F/# = 5.6,  $\beta = -0.15$
- - F/# = 8.0,  $\beta = -0.15$
- F/# = 4.0,  $\beta = -0.16$
- F/# = 5.6,  $\beta = -0.16$
- F/# = 8.0,  $\beta = -0.16$
- ⋯ F/# = 4.0,  $\beta = -0.18$
- ⋯ F/# = 5.6,  $\beta = -0.18$
- ⋯ F/# = 8.0,  $\beta = -0.18$



# 0 dpt, 480 mm WD F#/4

## Camera


Sensor size = 4104x3006 pixels

Nyquist limit = 144 lp/mm


Pixel size = 3.45  $\mu\text{m}$

## Light


White background illumination






## Center



## Edge



## Corner



USAF element: 4/2  
Line width ( $\mu\text{m}$ ): 27.84  
Lp/mm (object): 18  
Magnification: 0.137  
**Lp/mm (image): 131**

4/2  
27.84  
18  
0.137  
**131**

4/2  
27.84  
18  
0.137  
**131**

# -2.86 dpt, 900 mm WD F#/4

## Camera


Sensor size = 4104x3006 pixels

Nyquist limit = 144 lp/mm


Pixel size = 3.45  $\mu\text{m}$

## Light


White background illumination







## Center



## Edge



## Corner



USAF element:	3/3	3/1	3/1
Line width ( $\mu\text{m}$ ):	49.61	62.5	62.5
Lp/mm (object):	10	8	8
Magnification:	0.077	0.077	0.077
<b>Lp/mm (image):</b>	<b>130</b>	<b>103</b>	<b>103</b>

# 2.64 dpt, 320 mm WD F#/4

## Camera


Sensor size = 4104x3006 pixels

Nyquist limit = 144 lp/mm


Pixel size = 3.45  $\mu\text{m}$

## Light


White background illumination







## Center



## Edge



## Corner



USAF element: 4/5  
 Line width ( $\mu\text{m}$ ): 19.69  
 Lp/mm (object): 25  
 Magnification: 0.191  
**Lp/mm (image): 133**

4/3  
 24.8  
 20  
 0.192  
**105**

4/1  
 31.25  
 16  
 0.192  
**83**



# 2.64 dpt, 320 mm WD F#/5.6

## Camera


Sensor size = 4104x3006 pixels

Nyquist limit = 144 lp/mm


Pixel size = 3.45  $\mu\text{m}$

## Light


White background illumination







## Center



## Edge




## Corner



USAF element:	4/5	4/3	4/1
Line width ( $\mu\text{m}$ ):	19.69	24.8	31.25
Lp/mm (object):	25	20	16
Magnification:	0.191	0.192	0.192
<b>Lp/mm (image):</b>	<b>133</b>	<b>105</b>	<b>83</b>


# Comparison: F#/4 vs. F#/5.6 @320 mm WD

## Vertical Optical axis




**F#/4**



**Center**






**Edge**



**Corner**



**F#/5.6**



# Horizontal Optical Axis, @0 dpt, 480 mm WD F#/4

## Camera

Sensor size = 4104x3006 pixels


Nyquist limit = 144 lp/mm

Pixel size = 3.45  $\mu\text{m}$


## Light

White background illumination




### Center



### Edge



### Corner



USAF element: 3/5  
Line width ( $\mu\text{m}$ ): 39.37  
Lp/mm (object): 13  
Magnification: 0.137  
**Lp/mm (image): 93**

3/5  
39.37  
13  
0.137  
**93**

3/5  
39.37  
13  
0.137  
**93**

# Horizontal Optical Axis, @ 2.64 dpt, 320 mm WD F#/4

## Camera

Sensor size = 4104x3006 pixels

Nyquist limit = 144 lp/mm

Pixel size = 3.45  $\mu\text{m}$

## Light

White background illumination




### Center



### Edge



### Corner



USAF element: 4/2  
Line width ( $\mu\text{m}$ ): 27.84  
Lp/mm (object): 18  
Magnification: 0.191  
**Lp/mm (image): 94**

3/5  
39.37  
13  
0.192  
**66**

3/6  
35.08  
14  
0.192  
**74**

# Horizontal Optical Axis, @ 2.64 dpt, 320 mm WD F#/5.6

## Camera

Sensor size = 4104x3006 pixels

Nyquist limit = 144 lp/mm

Pixel size = 3.45  $\mu$ m

## Light

White background illumination




### Center



### Edge



### Corner



USAF element: 4/5  
Line width ( $\mu$ m): 19.69  
Lp/mm (object): 25  
Magnification: 0.191  
**Lp/mm (image): 133**

3/5  
39.37  
13  
0.192  
**66**

3/6  
35.08  
14  
0.192  
**74**




# Comparison: Vertical vs. Horizontal Optical axis @ 480 mm WD

Center




Edge

Corner

Vertical



Horizontal






# Comparison: Vertical vs. Horizontal Optical axis @320 mm WD

**Center**




**Edge**

**Corner**

**Vertical**



**Horizontal**



# Comparison: F#/4 vs. F#/5.6 @320 mm WD




## Horizontal Optical axis

Center




Edge

Corner

F#/4



F#/5.6





# Comparison: F#/4 vs. F#/5.6 @320 mm WD




## Horizontal Optical axis

Center




Edge

Corner

F#/4



F#/5.6



# 0 dpt, 480 mm WD F#/4

## Camera


Sensor size = 4104x3006 pixels

Nyquist limit = 144 lp/mm



Pixel size = 3.45  $\mu\text{m}$

## Light

Red background illumination




## Center





USAF element: 4/2  
 Line width ( $\mu\text{m}$ ): 27.84  
 Lp/mm (object): 18  
 Magnification: 0.137  
**Lp/mm (image): 131**

## Edge



USAF element: 4/2  
 Line width ( $\mu\text{m}$ ): 27.84  
 Lp/mm (object): 18  
 Magnification: 0.137  
**Lp/mm (image): 131**

## Corner



USAF element: 4/1  
 Line width ( $\mu\text{m}$ ): 31.25  
 Lp/mm (object): 16  
 Magnification: 0.137  
**Lp/mm (image): 117**




# Comparison Red vs. White light

Center

Edge

Corner

Red



White

